



2010 Footwear Catalog

Texon® Ultra Insole.

4. A mildly tapered "roller sole" for smooth, energy conserving propulsion. Acor's Line of Progression Technology



The Anatomy of Acor Footwear

Comfort: Genuine leather uppers and full interior X-Static® shoe lining.

Fit: Engineered for greater freedom, depth and heel fit.

Cushion: Two removable inlays which automatically mold to the foot with wear.

Flexibility: Scored insole with micro-flex zones allow maximum movement. Punched out counter-sink cushions ball of the foot.

Support: Line-of progression outsole. Made from light weight, polyurethane that cushions and supports the foot.

